




TURBOCLEAN™ HARD FLOORS WET/DRY VAC 3548 SERIES

What's in the Box?	3
User Interface	3
Assembly & Charging the Battery	3
Filling the Clean Water Tank	4
Cleaning Your Floors.....	5
Using the Self-Cleaning Cycle.....	6
After-Cleaning Care	6
Storing Your Machine.....	7
Troubleshooting.....	8
Warranty	8



Product Overview

1. Power Button
2. Mode Button
3. Clean-Out Cycle Button
4. Clean Water Tank
5. Dirty Water Tank Release Button
6. Dirty Water Tank
7. Brush Roll Window



Meet your new BISSELL product!

Go to **[support.BISSELL.com](https://support.bissell.com)** for a comprehensive walkthrough of your new purchase, including videos, tips, support, and more. Want to get started right away? This guide has all the information you need to set up your new product. Let's take a look...

IMPORTANT SAFETY INSTRUCTIONS



READ ALL INSTRUCTIONS BEFORE USING YOUR APPLIANCE.

When using an electrical appliance, basic precautions should be observed, including the following:



WARNING

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR INJURY:

- Unplug from electrical socket when not in use, before cleaning maintaining or servicing the appliance.
- Use indoors only.
- Do not immerse. Use only on hard floor surfaces moistened by cleaning process.
- Use only cleaning products intended for use with this appliance to prevent internal component damage. See the Cleaning Formulas section of this guide.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Do not use for any purpose other than described in this user guide. Use only manufacturer's recommended attachments.
- Do not charge with damaged cable or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors or dropped into water, have it repaired by a qualified technician.
- Do not pull or carry by cord, use cord as a handle, close door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep openings free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts of the appliance and its accessories.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible materials (lighter fluid, gasoline, kerosene, etc.) or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without filters in place.
- Risk of injury from moving parts. Brush roll may start unexpectedly. Turn OFF before cleaning or servicing.
- Turn OFF all controls, including the Power Switch and disconnect charger from electrical outlet before making any adjustments, performing maintenance, troubleshooting, changing accessories or storing appliance. Such preventative safety measures reduce the risk of starting the appliance accidentally.
- Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- Use only with charger SAW-30A-260-1000U.
- Battery pack, charging port on the appliance and charger output are not to be short-circuited.
- Do not use appliance that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not expose battery pack or appliance to fire or excessive temperature. Exposure to fire or temperature above 130°C/265°F may cause explosion.
- Follow all charging instructions and do not charge the appliance outside of the temperature range specified in the instructions. Charging improperly or at temperatures outside of the specified range may damage the battery and increase the risk of fire.
- Have servicing performed by a qualified repair person using only identical replacement parts. This will ensure that the safety of the product is maintained.
- Do not modify or attempt to repair the appliance except as indicated in the instructions for use or care.
- Keep the temperature range of between 4-40°C/40-104°F when charging battery, storing unit or during use.
- Do not charge the machine outdoors.
- Do not turn your appliance ON until you are familiar with all instructions and operating procedures.
- This appliance contains batteries that are non-replaceable.
- Do not incinerate the appliance even if it is severely damaged. The batteries can explode in a fire.
- The battery must be removed from the appliance before it is scrapped.
- Keep appliance on a level surface.
- Do not use appliance in an enclosed space filled with vapors given off by oil-based paint, paint thinner, some moth-proofing substances, flammable dust, or other explosive or toxic vapors.
- Do not use to pick up toxic material (chlorine bleach, ammonia, drain cleaner, etc.)
- Do not pick up hard or sharp objects such as glass, nails, screws, coins, etc.
- Plastic film can be dangerous. To avoid danger of suffocation, keep away from children.

SAVE THESE INSTRUCTIONS

THIS MODEL IS FOR HOUSEHOLD USE ONLY. COMMERCIAL USE OF THIS UNIT VOIDS THE MANUFACTURER'S WARRANTY.

IMPORTANT INFORMATION

- Keep appliance on a level surface.
- If your appliance has a motorized brush roll, do not leave machine running in the same spot without the handle fully upright.
- To reduce the risk of a leaking condition, do not store where freezing may occur. Damage to internal components may result.









WARNING

This product contains Lithium-Ion rechargeable batteries. DO NOT mix Lithium-Ion batteries with general household waste. According to Federal and State regulations, removal and proper disposal of Lithium-Ion batteries is required. For specific battery disposal instructions please contact Call2Recycle at 877-723-1297 or visit www.call2recycle.org. For full instructions on battery removal for recycling visit support.BISSELL.com.




What's in the Box?

					
Handle & Body	Brush Roll(s)	Trial Formula(s)	Clean-Out Brush & Strainer	Docking Station	Charging Adapter






User Interface

- 1. Brush Roll Obstruction Indicator
- 2. Dirty Water Tank Full/Missing Indicator
- 3. Battery Level Indicator
- 4. Clean Water Tank Empty Indicator
- 5. Water Spray Rate Indicator
- 6. Water Spray Rate Selection Button
- 7. Power Activation Switch (machine must be reclined)
- 8. Self-Cleaning Cycle Activation Switch



Assembly & Charging the Battery

Go to support.BISSELL.com for assembly videos.

		
1. Firmly insert the handle into body of machine until it clicks into place.	2. Plug charging adapter into docking station.	3. Plug the adapter into wall outlet.
		<p>Low Battery: One battery segment will flash blue.</p> <p>Charging Mode: Blue light will flash according to battery status.</p> <p>Charging Complete: All three segments will be solid blue.</p>
4. Place on the docking station to charge.	5. Fully charge machine before first use. Battery icon lights will indicate charge.	

Filling the Clean Water Tank

View our family of formulas for your family of mess-makers at [BISSELL.com](https://www.bissell.com).

Keep plenty of BISSELL® formulas on hand so you can clean whenever it fits your schedule.

Note: Only use BISSELL formulas in your machine. Other formulas or household cleaners may harm the machine. Do not use hard floor formula on area rugs or carpet.



Multi-Surface Formula

Great for cleaning sealed hard floors and refreshing area rugs.



Wood Floor Formula

Restores your wood floors' natural shine.



Hard Floor Sanitize






Cleans and sanitizes, eliminates 99.9% of bacteria.*



PET Clean + Natural Multi-Surface

Effective, plant-based cleaning formula.







*Kills 99.9% of Enterobacter aerogenes (ATCC 13408) and Staphylococcus aureus (ATCC 6538)

		
<p>1. The clean water tank is the top tank on the front of the machine. Press down on the button at the top of the tank and pull to remove.</p>	<p>2. Lift the flap and hold open.</p>	<p>3. Add warm (140°F/60°C max) tap water as indicated by the fill line on the tank.</p>
		
<p>4. Add BISSELL formula as indicated by the fill lines on the tank.</p>	<p>5. Release flap and press into place. Insert tank by lining up bottom edge and pressing until it clicks into place.</p>	

⚠ WARNING To reduce the risk of fire and electric shock due to internal component damage, use only BISSELL cleaning formula intended for use with the hard floor device.




Cleaning Your Floors

Go to support.BISSELL.com for how-to videos and cleaning tips.

		
<p>1. Recline the machine. Press the power button ON.</p> <p>Note: The unit must be reclined before power button will activate.</p>	<p>2. Press the WATER FLOW button to switch between LO, HI and Vacuum-Only Modes.</p> <p>LO Mode: Blue light flashing HI Mode: Blue light solid Vacuum-Only Spray Mode: No light</p>	<p>3. Solution will dispense automatically. Make forward and backward passes to clean your floors.</p>
		
<p>4. The clean water tank indicator will flash red when tank is empty.</p>	<p>5. The dirty water tank indicator will flash red when tank is full or removed.</p>	<p>6. Turn the machine OFF by pressing the power button and return machine to the upright position.</p>

Cleaning with Hard Floor Sanitize Formula


Please read "DIRECTIONS FOR USE" on Hard Floor Sanitize label. Use on hard nonporous floors only.

		
<p>1. Remove visible soil before cleaning. In HIGH Mode, make forward and backward passes.</p>	<p>2. Allow floor to remain visibly wet with formula for five minutes. This may require additional passes in HI mode.</p>	<p>3. In Vacuum-Only Spray Mode, make forward and backward passes to extract formula.</p>


ATTENTION

- This machine is designed to be used on sealed hard floors.
- Do not overwet hardwood floors. Be careful not to run over loose objects or edges of area rugs. Stalling the brush may result in premature belt failure.


Using the Self-Cleaning Cycle



1. Place the machine on the docking station. Make sure there is cleaning formula in the clean water tank and the dirty water tank is empty.



2. Press the self-cleaning button to start the cycle. The button light will pulse while cycle is running.



3. Once complete, remove the brush roll to dry. See "After-Cleaning Care" for instructions.

After-Cleaning Care


Go to support.BISSELL.com for a full list of how-to videos.




1. Empty the dirty water tank. To remove, press the button on the top of the tank, grab the front handle and pull tank out.




2. Hold the top of the tank near the sides of the filter and pull up to remove.




3. Use the strainer on the clean-out brush to strain debris out of dirty water while pouring into a utility sink or similar waste water receptacle. Dispose of debris in trash and rinse the tank.



4. Remove the pleated and mesh filters from the top of the tank by pulling up.




5. Wash filters with warm water and mild detergent. Rinse the bottom of the tank cover.
Note: Filters must be completely dry before reinstalling.




6. Remove the brush roll cover.


CONTINUED ON NEXT PAGE ➡




7. Pull the brush roll tab to remove. Pull the yellow tab of the brush roll filter to remove.




8. The brush roll, window and brush roll filter can be hand washed. Use the cleaning tool to scrub parts.




9. Use the hook on the cleaning tool to remove hair and debris from brush roll.




10. Remove the machine from the dock and wipe out the tray.




11. Leave all parts out to dry before reassembling.




12. Place the end of the brush roll into the left side of the foot. Press the tab of the brush down so it locks into place.



13. Replace the brush roll window by aligning window with foot. Press the window down until it clicks into place.



14. Reassemble the dirty water tank. **Note:** Filters must be completely dry before reinstalling.



15. Insert the bottom of the tank first. Pivot the top toward the machine until it clicks into place.

Storing Your Machine

Store your machine in a protected, dry area. Since this product uses water, it must not be stored where there is danger of freezing. Freezing will damage internal components and may void the warranty.

NOTICE

To reduce the risk of a leaking condition, do not store machine where freezing may occur. Damage to internal components may result.

! WARNING

To reduce the risk of fire, electric shock or injury, turn power OFF and disconnect plug from electrical outlet before performing maintenance or troubleshooting on the dock.

Troubleshooting

Below are some of the issues you may run into. If you don't see the issue you're experiencing below, visit support.BISSELL.com or contact Consumer Care.

Problem	Possible Cause	Remedies
Machine is not working	Clean water tank is empty.	Refill and reinstall tank.
	Dirty water tank full or not seated properly.	Empty and reseal tank.
	Brush roll window is not latched in place.	Reinstall brush roll window.
	Machine is not reclined.	Recline machine before pressing power button.
Reduced or no suction	The suction path is blocked.	Clean the suction path.
	The brush roll is entangled by hair and other objects.	Clean the brush roll.
Abnormal noise in motor operation	The suction path is blocked.	Clean the suction path.
Machine is not charging	Adapter not connected to charging station.	Check adapter connection to charging base.
Dirty water tank icon is flashing	Tank is full or removed.	Remove, empty and reinstall tank.
Brush roll icon is flashing	The brush roll is entangled by hair and other objects.	Clean the brush roll.
Self-cleaning cycle button is flashing	The cleaning cycle was cut off due to full dirty water tank.	Remove, empty and reinstall tank.
Can't complete self-cleaning cycle	The battery needs to be charged.	Fully charge before use.

Note: Any other servicing should be performed by an authorized service representative.

⚠ WARNING To reduce the risk of fire, electric shock or injury, turn power OFF and disconnect plug from electrical outlet before performing maintenance or troubleshooting on the dock.

Warranty

Limited 18-month warranty, may vary by state. Visit support.BISSELL.com or call 1-844-383-2630 for complete warranty information.

NOTICE Disconnecting the battery will destroy the appliance and invalidate the warranty.

♥ Every Purchase Saves Pets™

BISSELL proudly supports BISSELL Pet Foundation® and its mission to help save homeless pets. When you buy a BISSELL® product, you help save pets, too. We're proud to design products that help make pet messes, odors and pet homelessness disappear.

Visit BISSELLsavespets.com to learn more.



©2022 BISSELL Inc. All rights reserved.
Part Number 1631076 02/22 RevB