



WHAT YOU WILL NEED: hammer, 5 nails, level, pencil.

The panels are numbered on the back. The placement of the sawtooth on the back will indicate the top of the panel.

INSTRUCTIONS:

1. Hold PANEL 3 up the the center of the wall space where the panels are being placed. With a pencil, mark the top of the piece. Measure $\frac{1}{2}$ inches down from from this spot. Place your first nail here (see diagram).
2. Measure 16 inches to the left and 4 inches down from the first nail. Place your second nail here (see diagram).
3. Measure 11 inches to the left and 7 inches down from the second nail. Place your third nail here (see diagram).
4. Repeat steps 2 and 3 to the other side of PANEL 3.
5. When all the panels are placed on the wall they should be 1 inch apart.