

amazonbasics



Premium Gaming Headset for PC and Consoles (Xbox, PS4) with Desktop Mixer
Casque de Jeu de Qualité Supérieure pour PC et Consoles (Xbox, PS4) avec Mixeur de Bureau
Premium Gaming-Headset für PC und Konsolen (Xbox, PS4) mit Desktop-Mixer
Cuffie da Gioco Premium per PC e Console (Xbox, PS4) con Mixer da Tavolo
Auriculares Premium para Juegos de PC y Consolas (Xbox, PS4) con Desktop Mixer
Hoogwaardige Gaminghoofdtelefoon voor PC en Consoles (Xbox, PS4) met Desktop Mixer
PC およびコンソール (Xbox, PS4) 用高品質ゲーミングヘッドセット、デスクトップミキサー付

B07L8TTY9Z, B07L8VNJ91



English	3
Français	13
Deutsch.....	22
Italiano	31
Español	40
Nederlands.....	49
日本語	57

Welcome Guide • English

English

Français

Deutsch

Italiano






Español


Nederlands

日本語

Contents:

Before getting started, ensure the package contains the following components:

A		x1
B		x1
C		x1
D		x1
E		x1



A Microphone

B Adjustable earcups

C Adjustable headband

D 3.5 mm audio port

E 3.5 mm audio plug to headphones

F Volume control

G Microphone mute

H 3.5 mm audio plug

I USB A 2.0 plug

J Micro USB plug

K Headphones audio port for stereo headphones only

L Headphones audio port for stereo headphones with microphone

M EQ modes

Bass mode / Game mode / Movie mode / Music mode

N Micro USB port

O Volume control knob

Increase volume: Turn clockwise

Decrease volume: Turn anti-clockwise

Mute or unmute the volume: Press once

P Microphone mute LED indicator

Q Microphone mute button

IMPORTANT SAFEGUARDS



Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons including the following:


- To prevent possible hearing damage, do not listen at high volume levels for long periods, do not use the headphones while driving or cycling or in any situation where you should be able to hear other sounds.
- As a guide to setting the volume level, check that you can still hear your own voice when speaking normally while listening with the headphones.



Intended Use


- This product is intended to be used in dry indoor areas only.
- No liability will be accepted for damages resulting from improper use or non-compliance with these instructions.

Connecting to a PC / MAC



1. Plug the USB micro cable into the USB desktop mixer and your PC / MAC.
2. Plug the inline control cable into the headphones and audio port (L) on the desktop mixer.
3. Turn on your PC / MAC. The USB desktop mixer will turn on.
4. Set "Amazonbasics Pro Headphones" as the device for sound output and input in the sound settings of your PC / MAC. You may need to check your game's settings for additional set-up.
5. Now you can adjust volume setting / EQ modes using the desktop mixer.

Connecting to the PS4




1. Turn on your gaming console.
2. Plug the inline control cable into the headphones and 3.5 mm audio jack on DUALSHOCK®4.
3. Navigate to Settings>Devices>Audio Devices. Choose “Output to Headphones” and select “All Audio”.
4. Adjust the volume setting using the inline volume control.



WARNING

Extended exposure to high volumes when using your headset may result in permanent hearing loss.

Connecting to the Xbox One



1. Turn on your gaming console.
2. If your controller has a 3.5 mm audio jack, plug the inline control cable into the headphones and 3.5 mm audio jack on the controller.
Or
If no 3.5 mm jack is available, you will need the Xbox One Stereo headset adapter (not included) that plugs into the controller.
3. Double-tap the Xbox button on the controller, then navigate to settings and adjust as needed.
4. Adjust the volume setting using the inline volume control.

**WARNING**

Extended exposure to high volumes when using your headset may result in permanent hearing loss.

FCC – Supplier's Declaration of Conformity

Unique Identifier	B07L8TTY9Z - AmazonBasics Premium Gaming Headset for PC and Consoles (Xbox, PS4) with Desktop Mixer - Black B07L8VNJ91 - AmazonBasics Premium Gaming Headset for PC and Consoles (Xbox, PS4) with Desktop Mixer - Red
Responsible Party	Amazon.com Services, Inc
U.S. Contact Information	410 Terry Ave N. Seattle, WA 98109, United States
Telephone Number	(206) 266-1000

FCC Compliance Statement

1. This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
 - (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Canada IC Notice

- This Class B digital apparatus complies with Canadian CAN ICES-3(B) / NMB-3(B) standard.

Disposal



The Waste Electrical and Electronic Equipment (WEEE) Directive aims to minimise the impact of electrical and electronic goods on the environment, by increasing re-use and recycling and by reducing the amount of WEEE going to landfill. The symbol on this product or its packaging signifies that this product must be disposed separately from ordinary household wastes at its end of life. Be aware that this is your responsibility to dispose of electronic equipment at recycling centers in order to conserve natural resources. Each country should have its collection centers for electrical and electronic equipment recycling. For information about your recycling drop off area, please contact your related electrical and electronic equipment waste management authority, your local city office, or your house hold waste disposal service.

Cleaning and Maintenance

Cleaning

- To clean, wipe with a soft, slightly moist cloth.
- Never use corrosive detergents, wire brushes, abrasive scourers, metal or sharp utensils to clean the product.

Maintenance

- Store in a cool and dry place away from children and pets, ideally in the original packaging.
- Avoid any vibrations and shocks.

Specifications

Pro Gaming Headphones

Rated power:	10 mW
Connection:	3.5 mm plug
Frequency range:	20 Hz – 20 kHz
Sensitivity:	98 ± 3dB @ 1 kHz
Impedance:	32 Ω
Mic frequency range:	100 Hz - 10 kHz
Mic sensitivity:	-48 ± 4dB @1 kHz
Mic impedance:	≤2.2 kΩ
Inline volume control cable length:	6.5 ft (2 m)
Product dimensions:	7.8 x 7.7 x 3.5 in (198 x 195 x 90 mm)
Product weight:	10 oz (284 g)

USB Desktop Mixer

Power source:	5 V USB port
Current consumption:	100 mA max.
Frequency range:	20 Hz – 20 kHz
USB A 2.0 cable length:	6 ft (1.8 m)
Audio port (L):	4-pole 3.5 mm port
Audio port (K):	3-pole 3.5 mm port
Product dimensions:	82 x 65 x 30 mm
Product weight:	4.6 oz (130 g)

Warranty Information

To obtain a copy of the warranty for this product:



For US - Visit amazon.com/AmazonBasics/Warranty

For UK - Visit amazon.co.uk/basics-warranty



Contact Customer Service at:

US +1-866-216-1072

UK +44 (0) 800-279-7234



amazon.com/AmazonBasics

MADE IN CHINA
FABRIQUÉ EN CHINE
HERGESTELLT IN CHINA
PRODOTTO IN CINA
HECHO EN CHINA
GEMAAKT IN CHINA
中国製

V1-05/19