



Instruction Manual


Please save this manual for future reference.


Thank you for purchasing this Winsome House product. This product has been manufactured with the highest standards of safety and quality.

Product Name:	Set of 3 Solar Step Lights
SKU #:	WH093









Keyhole size: 3/8 inch; hardware not included.

Instructions

- Turn the on/off switch to the on position
- For best results, allow to charge in direct sunlight for a minimum of 8 hours
- · After fully charged, product will automatically light at night
- To extend battery life, turn to the off position when not in use
- Battery: rechargeable AA Ni-MH 300mAh 1.2V 1pc (include)

Trouble Shooting Tips:

If your solar light does not turn on at night, it may be caused by the following:

1. Check to see if the switch is in the "OFF" position.

Resolution: Push the switch to the "ON" position and allow the solar light to be charged for at least 8 hours in direct sunlight.

2. Battery may not be fully charged.

Resolution: Make sure the solar light is placed in an area where the solar panel receives the maximum amount of full direct sunlight everyday.

- 3. The solar light may be located too close to other light sources (such as porch light or street lantern). **Resolution:** Relocate away from external light source.
- 4. The rechargeable battery may need to be replaced.

Resolution: Replace with batteries of identical specification.