

















|   |   |  |  |
|---|---|--|--|
| A<br><br>1 | B<br><br>1 | C<br><br>L<br>1 | D<br><br>R<br>1 |
| E<br><br>1 | F<br><br>1 | G<br><br>5      | H<br><br>4      |
| I<br><br>8 | J<br><br>1 | K<br><br>1      | L<br><br>1      |
|   |   |  |  |



## WARNING

This chair is intended for home and office use.  
Make sure that all screws are tightened and check periodically.  
Clean the chair by using wet cloth and water. Do not use ingredients with chemicals.

## LIMITED WARRANTY

Any repair, replacement, or warranty service, and all questions should be directed to W Appliance Co. at 1 (855) 855-0294 from the USA or Puerto Rico. W Appliance Co. warrants to the original purchaser that the product will be free from defects in material, parts and workmanship for the period designated for this product. The warranty commences the day the product is purchased and covers up to a period of 1 year (12 months) for parts (manufacturing defects only). W Appliance Co. agrees that it will, at its option, replace the defective product with either a new or remanufactured product equivalent to your original purchase during the warranty period.