




Owner's Manual

Eufy Lumos Smart LED Bulb

Installing Lumos Smart Bulb



 Make sure the power switch controlling Lumos is turned off before installing.


 When the bulb is turned on, it will become hot as light is emitted. To avoid burning your hands, do not touch the bulb. Do not touch the bulb immediately after turning it off.

►1

Downloading the EufyHome App

What you need:

- A Wi-Fi router supporting the 2.4 GHz and 802.11 b/g/n bands; the 5 GHz band is not supported.
- A smartphone or tablet connected to a Wi-Fi network.
- A smartphone or tablet running iOS 8.0 (or above) or Android 4.3 (or above).




Download the EufyHome app from the App Store (iOS devices) or Google Play (Android devices).


►2

Connecting to a Wi-Fi Network

Note: Before starting Wi-Fi setup, make sure Lumos is turned on and blinks three times.











- 1 In the EufyHome app, tap the "+" icon in the top right corner to add "Lumos" to your EufyHome account (Different Lumos models have different names: Model T1011 - Lumos White; Model T1012 - Lumos Tunable; Model T1013 - Lumos White & Color).
- 2 Follow the on-screen instructions to complete setup.



-  - Make sure your smart device has already connected to your home network.
- The instructions in this manual are for your reference only. The app will be updated from time to time. Always follow the instructions in the app to complete Wi-Fi setup.

►3

Using Lumos with the EufyHome App

	Control Lumos remotely.
	Adjust the brightness of the bulb(s).
	Select White Light Mode (Model T1012 & T1013 only): Adjust the color temperature from warm white to cool white.
	Select Color Mode (Model T1013 only): Select a color for Lumos to emit.
	Select Flow Mode (Model T1013 only): Lumos will automatically change colors according to your color and time settings.
	Select Music Mode (Model T1013 only): Lumos will synchronize with the music being played and display different lighting effects.
	Set schedules for Lumos.
	Enable Away Mode: Lumos will randomly turn on and off during the set period of time.
	Add and manage groups of bulbs: This feature is only available for same-model bulbs.
	Enable multiple users to control Lumos: Lumos allows any member of the household to control the light. You just need to get the owner's permission in the app.

►4

Using Lumos with Amazon Alexa / the Google Assistant (Optional)

Before you start, make sure that:

- Lumos is connected with the EufyHome app.
- You have an Alexa-enabled device (i.e. Eufy Genie, Amazon Echo, Echo Dot and Amazon Tap) or a device enabled with the Google Assistant (i.e. Google Home). These devices are sold separately.
- The Amazon Alexa app or the Google Home app is already installed on your smart device, and you have created an account.

To control Lumos with Amazon Alexa:

- 1 Open the Alexa app and select "Skills" from the menu.
- 2 On the Skills screen, search for "EufyHome".
- 3 Once you have found the "EufyHome" skill, tap **Enable**.
- 4 Login with your EufyHome account so that Alexa can control your Lumos.
- 5 Discover new smart devices via the "Smart Home" menu in the Alexa app or Alexa voice control.
 - Once the device is found, you can control Lumos with your voice.

►5


- 6 Say simple commands to Alexa. Below are some examples:

Note: The default device name is "My Smart Bulb". You can modify the device's name in the EufyHome app.

"Alexa, turn on my bulb."

"Alexa, set my bulb to 70 percent brightness."

"Alexa, dim my smart bulb."



"Alexa, set my smart bulb to cool white. (Model T1012 & T1013 only)"

"Alexa, set my smart bulb to orange. (Model T1013 only)"

►6



For FAQs and more information, please visit
www.eufylife.com


T1011/T1012/T1013
51005000936 V04

To control Lumos with the Google Assistant:

Lumos now works with the Google Assistant on devices like the Google Home.

- 1 Open the Google Home app.
- 2 From the menu of the Google Home app, tap **Home Control**. If you cannot find **Home Control**, upgrade your app to the latest version.
- 3 Tap the "+" icon in the Device List and then select "EufyHome".
- 4 Follow the instructions in the Google Home app to authorize the Google Assistant with your EufyHome account.
- 5 After successful configuration, say simple commands to the Google Assistant to control Lumos with your voice.

Note: You can modify your device name in either the EufyHome app or the Google Home app.



"Ok Google, turn on My Smart Bulb."

"Ok Google, set My Smart Bulb to 70 percent brightness."

"Ok Google, dim My Smart Bulb."

"Ok Google, set My Smart Bulb to daylight. (Model T1012 & T1013 only)"

"Ok Google, set My Smart Bulb to orange. (Model T1013 only)"

Troubleshooting

1. Cannot connect to your Wi-Fi network.

- Make sure you are connecting Lumos to a 2.4GHz wireless network.
- Check if you have entered the correct Wi-Fi password during Wi-Fi setup.
- Check if there are any Internet connection problems. If the Wi-Fi signal is too weak, restart your wireless router and try again.

2. How to reset the Wi-Fi connection.

- Continuously turn the light off and on five times until the light blinks.

3. No response when using Lumos with the EufyHome app.

- Check if Lumos is turned off. If yes, turn it on and wait until Lumos reconnects with the Wi-Fi network automatically.
- Check if there are any Internet problems. If necessary, reset your wireless router and try again.
- If your smart device is connected to a 3G or 4G mobile network, check to see if the mobile network's signal is abnormal. Try again when the signal is stable.

4. Cannot control Lumos with Alexa voice control.

- Check if you have installed the Alexa app onto your smart device and enabled the "EufyHome" Skill in the Alexa app. For details, refer to the **Using Lumos with Amazon Alexa / the Google Assistant (Optional)** section of this manual.
- Check if you are using the proper commands when talking to Alexa. You must say the wake word "Alexa" first when making your request.
- Repeat your question. Speak clearly to Alexa.
- Make sure Lumos is at least eight inches away from walls or other objects that may cause interference (such as microwave ovens).
- Check if there are any Internet connection problems.

5. Cannot control Lumos with the Google Assistant voice control.

- Check if there are any Internet connection problems.
- Check if you have installed the Google Home app onto your smart device and enabled the "EufyHome" Skill in the Google Home app. For details, refer to the **Using Lumos with Amazon Alexa / the Google Assistant (Optional)** section of this manual.
- Check if you are using the proper commands when talking to the Google Assistant. When making your request, first say the wake words "Ok Google".

- Repeat your question. Speak clearly to the Google Assistant.
- Check if you have modified the name of Lumos in the EufyHome app. If yes, unlink your EufyHome account from the Google Home app and then relink.

Customer Service

- 🛡️ 18-month limited warranty
- 🔧 Lifetime technical support
- ✉️ support@eufylife.com
- 📞 +1 (800) 988 7973 (US) Mon-Fri 9:00 - 17:00 (PT)
+44 (0) 1604 936200 (UK) Mon-Fri 6:00 - 11:00 (GMT)
+49 (0) 69 9579 7960 (DE) Mon-Fri 6:00 - 11:00
+81 03 4455 7823 (JP) 月 - 金 9:00-17:00
+86 400 0550 036 (中国) Mon-Fri 9:00 - 17:30

- 📘 @EufyOfficial
- 📺 @EufyOfficial
- 📷 @EufyOfficial
- 📌 @EufyOfficial